

PSR-SX920 & SX720

PSR-340

VOICE

	Voice Name	Voice Type	Voice Number		
			MSB#	LSB#	Prg#(1)
1	Steel Guitar 340	Regular	50	3	1
2	Muted Guitar 340	Regular	50	3	2
3	Finger Bass 340	Regular	50	3	3
4	Strings 340	Regular	50	3	4
5	Standard Kit 340	SFX	126	1	50

STYLE

Style Name	Style Type
01 FlkRckPeruano1	Normal
02 FlkRckPeruano2	Normal
03 CumbiaPeruana	Normal
04 Reggaeton1	Normal
05 Reggaeton2	Normal
06 SalsaRomantica	Normal
07 Merengue1	Normal
08 Merengue2	Normal
09 Bachata	Normal
10 Vallenato	Normal
11 TangoArgentino	Normal
12 Gaita	Normal